

# Dynamic Spectral Imports in TSG

Peter Mason, August 2017

## Introduction

When you create a TSG dataset, you start out by selecting all spectra that you want to go into it. You can't add any spectra to the dataset after it has been created<sup>1</sup>.

Well, that's in the past for field-spectrometer datasets as things have changed. TSG has new functionality termed "dynamic import". It was motivated by requests for TSG to be more supportive of a field-spectrometer workflow.

Having prepared a starter or "template" dataset with at least one spectrum, some calculated scalars and some plots, you can now have TSG watch for new spectra and add them to the dataset as they arrive. Scalars (including TSA or CLS interpretations) are calculated for the new arrivals and plots are updated.

The system is only for field-spectrometer datasets – ones that just have spectra, scalars and possibly some sample pictures. It is not offered for HyLogging datasets as they would require more complex data (not just spectra).

A lightweight version of the system is also available for *all* spectral datasets, including HyLogging ones. Here, new arrivals are added to the Floater Scratchpad instead of the main dataset.

## Quick facts

- You can add compatible spectra to a plain field-spectrometer TSG dataset
  - Date and (in some cases) GPS scalars are imported too
  - Calculable scalars are calculated; other scalars get NULL
  - Plots are updated
- You can add compatible spectra to a Floater Scratchpad
- Supported import formats are:
  - PANalytical ASD binary files
  - Spectral Evolution OreXpress .SED ASCII files
  - Generic ASCII x,y files
- The current add methods are:
  - Directory watch
  - Drag & drop
- Dynamic import settings are remembered for the dataset

## Quick flow

### Dynamic dataset

1. Prepare a field dataset (optional if you have one already)
2. Configure the dynamic import
3. You're ready. Start collecting!

---

<sup>1</sup> Yes you could *merge* TSG datasets but that's quite a cumbersome process.

## Scratchpad

1. Open a dataset, then bring up a Floater and put it in Scratchpad mode (📄)
2. Configure the dynamic import
3. You're ready. Start collecting!
4. Remember that you have to save the scratchpad manually. TSG won't do this automatically.


## Preparing a dataset

This section does not apply to the Scratchpad import. Also, if you already have a field dataset then “dataset creation” doesn't apply.

## Dataset creation

### Extra space

When importing ASD, OreXpress or generic ASCII x,y files, you will find a new control in page 3 of TSG's import wizard.



TSG can now leave empty space in a field dataset. This setting controls how much extra space is allocated, over and above the spectra being imported now. Enter a number in accord with how much dynamic importing you expect to do later.

Leaving empty space speeds up the process of adding spectra dynamically later on, as the dataset is only expanded when it runs out of room. Dataset expansion is a relatively slow process and you wouldn't want it to happen each and every time a new spectrum was added dynamically.

This setting doesn't just affect the dataset at the time it is created; it is also used later. Whenever the dataset runs out of room (in the future), it will be expanded by this amount. Don't worry, *you can adjust this setting later*, as the Dynamic Import Control Panel (see below) has the same field (called “File inc” there).

Extra space remains in the dataset until it is used up by dynamic imports. If you have “Copy .BIP file on open” turned off in [File -> Settings \[System\]](#), you can purge extra space by saving the dataset to a different name with [File -> Save as...](#)

### Import-time scalars

If you are importing ASD binary or OreXpress ASCII files then TSG will give you the option to import **GPS** scalars from metadata in the files. If you know that your files have valid GPS metadata then it is useful to import these scalars. You will find the same GPS option in the Dynamic Import Control Panel.

**Date** is always imported. It comes from metadata for ASD and OreXpress formats, and is taken from a file's oldest timestamp for the generic ASCII x,y format.

### Wavelength resampling

One would normally have the same sort of raw spectrum files (e.g., all ASD binary) at dataset-creation time and (later) when doing dynamic imports, but *this is not a requirement*<sup>2</sup>. The

---

<sup>2</sup> You can actually mix & match files from different spectrometers but if you do that then please bear in mind the differences in *actual* spectral resolution, reflectance calibration, and noise characteristics.

important thing to note is that when you do dynamic imports later on, the new files must have a wavelength range that is at least as broad as the host dataset's. Also, it is best to resample the new files in the same way as in the primary import.

New to this release of TSG is the “**Plain L3**” resampling algorithm on import. It's a 3-lobe Lanczos resampling algorithm; good for general resampling. Try it. You will find the same option in the Dynamic Import Control Panel.

## Scalars and plots


Whenever a new spectrum is added to the dataset, calculable scalars will get calculated for it and plots will get updated. Make use of this. Sure you could have TSG's Spectrum screen open and view the spectrum of each new measurement as it arrives, but TSG has more to offer. Here are some simple examples.

- Have a TSA-mode floater open (see below).
- Have the Stack screen open.
- Have the Log screen open, displaying the usual TSA results.
- Have the Log screen open, displaying some spectral-index and / or *User-TSA* scalars that you have set up. Perhaps have a floater or two up as well.

## TSA

TSA scalars will also be recalculated for newly-added spectra. Any dataset with sufficient spectral coverage will have System TSA scalars, and if you set up **User TSA scalars** then they will be calculated too. If you are working in a well-constrained geological environment then we recommend that you set up an environment- or deposit-specific Active-Minerals list for your User TSA scalars, then apply this list to new datasets. This will give you more reliable User TSA results.

## Setting up an Active Minerals List



You should come in with a fair idea about what minerals you might expect to find in your environment / deposit. You will need a dataset that contains enough representative spectra to judge things by. Examine the dataset's System TSA results. Identify any minerals that TSA found but shouldn't have, and spend some time examining such spectra to check if perhaps TSA is actually telling you something that you didn't know about your environment. Also identify minerals TSA missed but should have found. Confirm the minerals that TSA rightly didn't find. Start editing the list once you're ready.

- Use TSG's **File -> Settings** menu to bring up the Settings dialog.
- Switch to the **TSA** tab.
- If necessary, change the **TSA result set** selection.
- Click the **Select active minerals** button. You will get another dialog called **TSA Item Selection**. Use the checkboxes to turn items on and off.

Once you **Proceed** out of item selection and **OK** out of Settings, User TSA scalars will be created if necessary, and (re)calculated. Examine these User TSA results and perhaps do another round of list editing.

Once you have settled on an Active-Minerals list, you should save it to an external file.

- The **TSA Item Selection** list has a **right-click menu**.
- Right-click on the list and select **Save to file...**
- Pick a good filename and subdirectory so that you can find this file easily in the future.

## Applying an Active Minerals List to another dataset

Say you're starting another round of sampling and have created a starter / template dataset for it. With this dataset open in TSG:

- Bring up **Settings[TSA]** and the **TSA Item Selection** dialog as described above.

- Right-click on the list and select **Load from file...**
- Load the active-minerals file that you saved earlier.

Once you **Proceed** out of item selection and **OK** out of Settings, suitably-subsetted User TSA scalars will be created and calculated.

## CLS scalars

Advanced TSG users may know about the option to create CLS (Constrained Least Squares) unmixing results using TSG's "Parameter Wizard" (**Edit -> New scalar** menu). These scalars and their uses are described elsewhere. In short, the CLS algorithm is simpler and faster than TSA. It copes easily with high mixture levels but very much depends on a tight and sensible Restricted Minerals Set being configured by the analyst. Importantly, *CLS scalars work through Domain Restricted Minerals Sets*. They do not work through the dataset-global Active Minerals List described above. (The lists look very similar but the mechanism is different.) If you have CLS scalars, you should use TSG's Domain editor to set up the Restricted Minerals Set for the default domain.

## Dynamic Import Control Panel

This dialog lets you configure the dynamic import. If you have a dataset open then you can bring up the control panel using TSG's menu:

### **File -> Import -> Dynamic import settings...**

If you have an old dataset then you will need to set things here before you can attempt a dynamic import. If your dataset was created by a version of TSG8 from August 2017 or later then a number of settings will have been carried over from the import and the drag & drop method will be ready to go.

Some internal settings can't be established until TSG has seen the first dynamic arrival, so (to be sure) TSG pops up the control panel automatically on this occasion.


*Select and configure the format of your raw spectrum files*

*Select "watch" method(s)*

*Configure "watch" directories*

*Configure spectral resampling; set the increment for when the dataset runs out of room*

*Dynamic import can add spectra to the main dataset or the Floater scratchpad (or even both)*



## Format of incoming raw spectrum files

TSG currently supports one of three formats here:

- PANalytical ASD binary files
- Spectral Evolution OreXpress .SED ASCII files
- Generic ASCII x,y files


Select your **Format** from the list.

TSG does not expect this to chop and change. If you want to switch to a different format then you should first select and configure it here.

Click the **Configure** button to bring up a small control panel with format-specific options. If the main dataset was created with a relatively new build of TSG8 then, as noted earlier, some settings will be carried over from the original import.

## Configure – ASD binary

You will find the same options that are in the “ASD” page of TSG’s Import wizard.



- Turn on **Remove inter-detector steps** to have TSG reduce discontinuities at the ASD’s detector boundaries (recommended). The FieldSpec spectrometer has 3 detectors and it is common to find steps in spectra at the points of change (commonly near 1000 and 1830 nm). A typical reason for this is small differences in surface coverage presented to the detectors by the instrument’s optical fibres.
- Use the **Smooth sides** options to smooth spectra over the short- and / or long-wavelength ends of the range. ASD spectra are often relatively noisy on the sides (e.g., 350 to ~420 nm and ~2300 to 2500nm). Factors may include relatively low illumination energy, optical throughput, and detector response. The list lets you select a smoothing amount and the two fields let you adjust the smoothing intervals.
- If you know that your files have valid GPS metadata then turn on **Import GPS data too** to have TSG import the data as **Easting**, **Northing** and **Depth** scalars.


## Halo spectrometer

The Halo itself deals with the procedure of building up a collection of spectra. It collects a number of binary ASD files, along with a text file that lists the files and has additional data (including mineral-match and other calculated scalars). At a suitable time the collection is transferred from the Halo to a PC. Such a collection and workflow is not a good match for TSG’s Dynamic Import functionality. Use TSG’s normal Halo import route instead.

## Configure – OreXpress


There isn’t much to configure here.

- At the moment there is only one **File format** option: .SED ASCII files. Another option may be added in the future.
- OreXpress files may include GPS metadata. If you know that these values are valid then turn on **Import GPS data too** to have TSG import **Latitude**, **Longitude** and **Altitude** scalars. (Name change pending.)



## Configure – ASCII XY

- Your files may have one or more “header” lines before coming to the columns of x,y, data pairs. Open one or two files in a text editor and take a look. TSG can’t process header lines. If you find any, tell TSG in the **Number of header lines** field.
- Your spectra might have reflectance expressed as percent (ranging [0,100]). TSG wants [0,1]. Open one or two files in a text editor and look at the Y (second column) values. If you see some values that are well over 1.0 then you probably have percent and should tick the **Incoming spectra range [0,100] %** checkbox.



## New arrivals

Currently there are two ways in which TSG can “watch” for new spectra to arrive: **Drag & drop**, and **Directory watch**. They apply to the main dataset and floater scratchpad imports. You can have one or both “watch” methods active.

### Drag & drop

There’s no rocket surgery here. With a dataset open in TSG, drag & drop a file from a Windows Explorer window to the main TSG window (main import) or a Floater Scratchpad window (scratchpad import).

- This system only supports one file at a time.

### Directory watch

Here’s the idea: Set up your spectrometer’s operating software to save spectra to a certain subdirectory as they are measured. This will be the **Watch** subdirectory. Create a separate subdirectory for TSG to move spectrum files to, once they have been imported. This will be the **Move to** subdirectory. In the Dynamic Import Control Panel, turn on **Directory watch** and configure the subdirectories.

Here are some rules:

- The Watch directory is for spectrum files only. Do not create the dataset there, and do not put any other files there. Also, you must not have any lower-level subdirectories in this directory.
- TSG will check the Watch directory for files every second or two. As soon as a file shows up, TSG will:
  - Move the file to the Move subdirectory.
    - If the file is locked (e.g., still open in some other program) then TSG will retry for a few seconds. If it stays locked or can’t be moved then TSG will **turn off directory watch**.
    - If there already is a file of the given name in the Move subdirectory then the old file will be *overwritten*.
  - Try to import the file.
    - If there was a problem with the import (e.g., it isn’t actually a spectrum file) then TSG will change the filename by inserting “xxx” at the start.
- If two or more files show up together in the Watch directory then TSG will handle each file.



## Resample

If the raw spectrum files do not have exactly the same wavelength spec as the host dataset then they will have to be resampled. Select the resampling algorithm here.

It is recommended that dynamic imports be resampled with the same method as the spectra in the original dataset import. If the host dataset was created by a recent build of TSG8 then the original resampling method will be carried over and shown as the default here.

## File inc

This is for importing into the main TSG dataset, and is essentially the same field as the one described in “Data set creation, Extra space” above. (See the description there).

Although dataset expansion is automatic, you wouldn’t want it to happen for each new spectrum as it slows things down. Entering a number greater than 1 will streamline the dynamic import process, as new spectra will go into reserved “empty” space when possible and the dataset will only get expanded when it runs out of room.

For general use I’d say set “File inc” to about 1/10 or 1/5 the current dataset size. Set it to 0 to let TSG decide (a last resort).

## Active

- Select **Dataset import** to have new spectra imported into the main TSG dataset. (This option is greyed out for complex datasets, e.g., HyLogging datasets.)
- Select **Scratchpad import** to have new spectra imported into the Floater scratchpad. You need to have a floater up and in Scratchpad mode for this to work.

If you really want to, you can have both of these options active.